



A step by step guide for ROOFBOND

Roof restoration – Colorbond® or Zinalume®

Step 1: High pressure wash roof using a 3600 p.s.i. water blaster. Try to remove chalkiness, mould and dirt.



Step 2: Apply 1 primer coat using Shieldseal W Plus using an airless machine and a 517 tip size. Do not apply too thickly and do not have runs occurring in the valleys of the tiles.
(Note: photo shown is Shieldseal W Plus being applied to a Colorbond roof)



Step 3: Apply one coat of Roofbond paint in the chosen colour by using an airless and a 521 tip.



Step 4: Apply the 2nd coat of Roofbond paint in the chosen colour by using an airless and a 521 tip.



Step 5: Clean up site and Machinery.



SHIELDCOAT PTY LTD

Unit 2/1075 Beaudesert Rd, Archerfield Q 4108

Phone: (07) 3274 6911 Fax: (07) 3274 6414

Email: info@shieldcoat.com.au Web: www.shieldcoat.com.au